

Application & Washing Instructions

AUTO-STORM[®] CLASSIC

1. Auto-Storm CLASSIC is ment for Carport use, with no direct rain or UV sunlight. It can also be used as a dust cover for indoor use.
2. Vehicles should be parked on firm, dry ground such as asphalt, sand, gravel or stone. Grass, earth and soil will attract humidity from below! We recommend removing Auto-Storm CLASSIC from time to time in order to ventilate.
3. Washing instructions: Wipe down with a mixture of diluted "All Purpose Cleaner" (eg. "Mr. Proper"). Do not use soap or detergent. We recommend wiping the cover down whilst on the car. Rinse well with cold water and hang to dry.

AUTO-STORM[®] AQUA

1. Vehicles should be parked on firm, dry ground such as asphalt, sand, gravel or stone. Grass, earth and soil will attract humidity from below! We recommend removing Auto-Storm AQUA from time to time in order to ventilate.
2. First cover the vehicle with the thicker 4-ply "Auto-Storm" and then follow with the lighter 1-ply "AQUA" cover over top. Fit the three Storm Straps around the width of the car, one at the front, one in middle and one at the rear of the car. For the simplest solution lay the Storm Straps on the ground and drive the car over them, then fold the straps over the car, clip the buckles and adjust.
3. Washing instructions: Both covers can be wiped down with diluted "All Purpose Cleaner" (eg. "Mr. Proper"). Do not use soap or detergent. We recommend wiping the covers down whilst on the car. Rinse well with cold water and hang to dry.

AUTO-STORM[®] AQUA-UV

1. Vehicles should be parked on firm, dry ground such as asphalt, sand, gravel or stone. Grass, earth and soil will attract humidity from below! We recommend removing Auto-Storm AQUA-UV from time to time in order to ventilate.
2. First cover the vehicle with the thicker 4-ply "Auto-Storm" and then follow with the lighter silver colored "UV" cover over top. Fit the three Storm Straps around the width of the car, one at the front, one in middle and one at the rear of the car. For the simplest solution lay the Storm Straps on the ground and drive the car over them, then fold the straps over the car, clip the buckles and adjust.
3. Washing Instructions: Both covers can be wiped down with diluted "All Purpose Cleaner" (eg. "Mr. Proper"). Do not use soap or detergent. We recommend wiping the covers down whilst on the car. Rinse well with cold water and hang to dry. The silver Top Cover can be hand washed at 30°C (eg. in a bath tub).).

AUTO-STORM[®] UV+

1. Vehicles should be parked on firm, dry ground such as asphalt, sand, gravel or stone. Grass, earth and soil will attract humidity from below! We recommend removing Auto-Storm UV+ from time to time in order to ventilate.
2. Cover the vehicle and fit the three Storm Straps around the width of the car, one at the front, one in middle and one at the rear of the car. For the simplest solution lay the Storm Straps on the ground and drive the car over them. Now fold the straps over the car, clip the buckles and adjust.
3. Washing instructions: Auto-Storm UV+ can be hand washed at 30°C (eg. in a bath tub). Wash with a dilution of "All Purpose Cleaner" (eg. "Mr. Proper"). Do not use soap or detergent. Rinse well with cold water and hang to dry.