

# PermaPack®

(For general use)

## DIRECTIONS

Please note that the plastic seal should be kept intact until the PermaPack® cylinders are ready for use. The drying agent inside the cylinders will absorb moisture as soon as the seal is broken. Remove the brown paper wrapping prior to use.

When no longer in use place the PermaPack® cylinders in a dry and ventilated location and regenerate prior to usage.

It is recommended that the cylinders be regenerated once the following maximum saturated weight has been reached:

**18cm/7" - cylinder 1900g**

**6cm/2.5" - cylinder 700g**

### Regeneration Procedure:

1. Preheat household oven to 220°C (430°F). Place the PermaPack® cylinders into the oven and bake for approx. 4 - 5 hours. Allow the cylinders to cool down while the oven is switched off, keeping the door closed. We recommend regenerating the cylinders in the evening and removing the cylinders the following morning. Once cool, the cylinders will be ready for renewed application.
2. PermaPack® cylinders can be regenerated in an oven again and again. Similar to that of a battery, the life span of PermaPack® will eventually come to an end. In order to guarantee ideal conditions for storage and full capacity of the desiccant, it is recommended that the PermaPack be replaced on the expiry date indicated on the cylinders.

**Please keep directions with PermaPack®**

**Active, do NOT open until ready for use**